



# Typ 0 601 611 0.. = GOF 1600

Stand | 90-99  
Issue | 94-09




Stand } ~~90 - 03~~  
Issue } 94 - 09



# Typ 0 601 611 0.. = GOF 1600

Neue Ausführung  
New Execution  
Nouvelle Exécution  
Nueva Ejecución



Alte Ausführung  
Old Execution  
Ancien Exécution  
Vieja Ejecución

