

**IMPORTANT:** A model label appears on the transaxle housing. If 618-0027 appears on your transaxle, use this illustrated parts list. For model 618-0076, refer to pages 30 & 31.

