



IMPORTANT: A model label appears on the transaxle housing. If 618-0002 or 618-0032 appears on your transaxle, use this illustrated parts list. For model 717-0542, refer to pages 38 & 39.

