

IMPORTANT: A model label appears on the transaxle housing. If 618-0076 appears on your transaxle, use this illustrated parts list. For model 618-0027, refer to pages 28 & 29.

