






GRASSCATCHER GC11678A (Model 43)

EJECTOR CHUTE CH84209G
(Optional Extra)



BUSH CH83215A
TORSION SPRING CH84724A
FLAP CH83334G
SPACER CH83214A





KNOB CH84723A
PUSH-ON-FIX HA25318D

R.H. LOWER HANDLE CH84509G
SAFETY SKIRT CH82897A

RAMP CH84939A
KNOB CH82917A
HEIGHT ADJ. HANDLE CH82916A
HEIGHT ADJ. SPRING CH82904B
RIVET CH84324B
REAR AXLE ASSY. CH84905A

8" WHEEL ASSY. CH85688A



HANDLE CH84507G

WASHER HA22228D
LEVER ASSY. CH85091A




NUT HA25845D


L.H. LOWER HANDLE CH84508G

BOLT CH84816D

PLATE CH84512D



SPRING CH84942A
PUSH-ON-FIX HA25193D
CONN LINK CH84980D
CIRCLIP HA25131D
PLUG HA25550A



BASEPLATE ASSY. CH85771N

SEGMENT CH82898A
RIVET HA25167A

CLIP CH84899B
BUSH CH82399A



AUX. RAMP CH85165A
SCREW HA20290D

FRONT AXLE CH84982D
SCREW HA21228D
CLIP CH80970B
NUT HA24927D



BLADEHOLDER ASSY. CA09320K



BLADE SET CA09308S

NUT, BOLT & WASHER SET CA09277S

