


Typ 0 601 611 0.. = GOF 1600

Stand | 90-93
Issue | 94 - 09




Stand } ~~90 - 03~~
Issue } 94 - 09



Typ 0 601 611 0.. = GOF 1600

Neue Ausführung
New Execution
Nouvelle Exécution
Nueva Ejecución



Alte Ausführung
Old Execution
Ancien Exécution
Vieja Ejecución

