

E3-02231B-01

INSTALL SPRING FROM
BACK OF BRACKET

